## Repair **Cherry Interior Wood Finish**

Item Needed: \Cherry W/S Stain

220 Sand Paper

Mohawk Satin top Coat part # 1015784

Mohawk Sealer part # 1015701

M10 2= 0413

Pant # 100 906 Spray NO Blush

M-100760

Light Blemish:

M102-0452

1 Sand blemish lightly until gone

2 Touch up with satin top coat until desired look

Heavy Blemish:

1 Sand blemish until gone

- 2 Restain area that has been removed due to sanding blemish. Continue to stain until the color match is complete allow to dry for 10 minutes
- 3 Apply Mohawk Sealer, allow to dry for 20 minutes. Sand between coats apply as many as needed.
- 4 Apply Mohawk satin top coat until desired look

Some situations require all wood finish to be removed due to the blemish being too deep to blend back with existing wood finish. In this case, it's less time to start fresh