



HUNTER 27 BIMINI INSTALLATION INSTRUCTIONS

You will need a drill, a 3/16” drill bit and a Phillips screwdriver.

1. Your first step in installing your frame is finding the location of the mounts. Measure forward 9” (from the center of the stern rail post). This measurement will be center of the mount (see picture #1). Secure the mounts with #10 x 1 1/4” pan head screws. Be sure to seal all the holes with 5200 caulk or silicone. Once these mounts have been secured, mount your frame, making sure the longest frame is facing aft. (see picture #1).

2. Take the longest stiff leg (attached to the aft frame) and slide it into the eye end on the fwd frame (see picture # 2) and secure. This eliminates the need for bimini tie down straps.

3. Attach the split rail mounts to the stern rail seats, and then take the smaller stiff leg that is (attached to the aft frame) and secure the eye end to the split rail mounts.

HARDWARE PACKAGE:

- (2) Stainless Split rail mounts
- (2) stainless Strait mounts



(Picture #1) Measure 9" fwd to find center of mount



(Picture #2) Longest stiff leg



(picture #3) attach the smaller stiff leg

