

## 356 SOP 120 VOLT RECEPTACLE INSTALLATION



1. In the module stage a 120 volt outlet will be wired and placed into a box and left just aft of the aft galley bulkhead, as the piece of furniture (the Q-berth hanging locker) will not be installed yet (it is installed in the pre-deck stage). All that will need to be done is to place the box thru the cutout on the aft side of the hanging locker and secure it by tightening the screws which will turn the flaps on the back of the box.
2. After the box is secured attach the cover plate to the outlet.
3. Once the CO monitor and the 12 volt outlet have been installed place the wires in conduit and run them down the aft-outboard corner of the locker securing them to the locker with cable ties.
4. Finally the back of the outlet will need to be covered with an black ABS 4 way outlet cover (see ABS cover SOP)

Revision Dates:

Expected Time:

Page