

356 CHART LOCKER ACCESS PANEL SOP INSTALLATION



#	Qty.	Description	Size	Part #
1	1	Chart Locker Aft Panel	356	
2	1	Chart Locker Shelf	356	
3	1	Chart Locker Drop In	356	
4	2	Fwd Batten	7/8" x 7/8" x 13"	
5	4	Batten Fasteners	#10 x 1-1/4" FH	461370
6	2	Panel Fasteners	#10 x 1" FH	461050

1. Unsnap and remove the chart locker door.
2. The chart locker panel and shelf are located under the chart locker desk.
3. On the back side of the panel across the bottom edge, cut a 30 degree angle. Sand rough edges smooth.
4. On the front side of the panel fwd and aft, place 2 - #10 x 1" FH screws going into the wood about 1/4" deep. These are temporary to help remove the panel for adjustments.
5. Fit and scribe the sides of the panel to fit the outboard wall, cut and adjust as needed to fit.
6. Once the panel has the correct fit place it into position in the access, mark the fwd and aft sides of the chart locker, for installation of the battens.
7. Using a C7 drill assembly, countersink 2 holes in each batten, one on each end (1" from the ends).
8. Place the battens on the outboard sides of the chart locker, 1/4" outboard of the marks.
9. Secure battens using designated fasteners.
10. Remove the screws from the panel, using C7 drill assembly countersink the two holes in the panel.
11. Secure the panel to the battens using designated fasteners.
12. Place shelf into the locker and drop in into the floor.
13. Snap door into place.

Revision Dates:

Expected Time: 20 min.

Page