

356 SOP FINISHED FLOORS INSTALLATION

#	#Ea	Description	Size	Part #
1	1	Main Cabin Fwd Floor	356	
2	1	Port V-Berth Floor	356	
3	1	Starboard V-Berth Floor	356	
4	1	Port Main Center Floor	356	
5	1	Port Main Aft Floor	356	
6	1	Chart Locker Floor	356	
7	1	Strbd. Main Fwd Floor	356	
8	1	Fwd Mast Post Bilge Cover	356	
9	1	Aft Mast Post Bilge Cover	356	
10	1	Strbd. Main Aft Floor	356	
11	1	Fwd Main Bilge Cover	356	
12	1	Center Main Bilge Cover	356	
13	1	Aft Main Bilge Floor	356	
14	1	Galley Fwd Floor	356	
15	1	Galley Aft Floor	356	
16	1	Aft Cabin Q-Berth Floor	356	
17	1	Fwd Floor Bilge Cover	356	
18	1	Aft Main Bilge Cover	356	
19	1	Strbd. Galley Bilge Cover	356	
20	60	Finished Floor Fasteners	#10 x 1" F/H	461050



1. Place the forward main floor in position (Located between the forward and starboard main bunks).
2. Place the port V-berth floor in position (Located in V-berth area).
3. Place the starboard V-berth floor in position (Located in V-berth area).
4. Place the port main cabin center floor in position (Located aft port side of forward main floor).
5. Place the port main cabin aft floor in position (Located aft port side of center main floor).
6. Place the chart locker floor in position (Located on top of chart locker step).
7. Place the starboard fwd main cabin floor in position (Located aft of starboard bunk).
8. Place the fwd mast post bilge floor in position (Located fwd of the mast post).
9. Place the aft mast post bilge floor in position (Located aft of the mast post).
10. Place the starboard aft main cabin floor in position (Located aft of starboard main cabin floor).
11. Place the forward main bilge cover in position (Located aft of aft mast pole floor). This will not be secured.
12. Place the center main bilge cover in position (Located aft of forward main bilge cover). This will not be secured.
13. Place the aft main bilge floor in position (Located aft of center main bilge cover).
14. Place the forward galley floor in position (Located in galley area).
15. Place the aft galley floor in position (Located aft of forward galley floor).
16. Place the aft stateroom floor in position (Located in aft state room or Q-Berth area).
17. Place the forward main cover in position (Located in the main cabin fwd floor). This will not be secured.
18. Place the aft bilge cover in position (Located aft of aft main bilge floor). This will not be secured.
19. Place the aft galley bilge cover in position (Located in the aft galley floor). This will not be secured.
20. All floors that are not going to be secured should have a 1/16" gap all around so they can be lifted out when needed.
21. All floors should fit properly and adjustments made from outer edges of outboard floors before securing finished floors to the sub-floors.
22. Do not drill into the holly strips. Use a C-7 drill assembly and designated fasteners, secure the appropriate floors in the designated places.

356 SOP FINISHED FLOORS INSTALLATION

