

# 356 SOP HEAD HANDRAIL INSTALLATION



#	Qty.	Description	Size	Part #
1	1	Handrail	N/A	
2	6	Handrail Fasteners	#8 x 5/8" P/H	466970

1. The handrail will be located on the aft inboard wall of the headliner in the head area.
2. Measure 8 1/2" outboard of the aft inboard corner and 3" up from the bottom edge of the headliner.
3. Place the handrail in position, the bottom of the handrail at the 3" mark on the head liner.
4. Mark the mounting hole locations, then drill the marked locations using a 1/8" drill bit going 1/2" deep and secure the hanger to the head liner using designated fasteners.

Revision Dates:

Expected Time: 5 min.

Page