

## 36 SOP MICROWAVE INSTALLATION



1. Remove the microwave face (there are two latches and the face just pulls off).
2. Record the serial number and model numbers from the back of the microwave by writing them down in the boat log book.
3. Plug microwave into the outlet located in the fwd outboard end of the microwave cabinet.
4. Center the microwave into the cabinet by placing the rubber feet of the microwave into the cutouts in the floor of the microwave cabinet.
5. Place the plywood on top of the microwave. This will help keep the microwave from moving.
6. Replace the front face of the cabinet.

Revision Dates:

Expected Time: 5 min.

Page