

## 356 SHOWER DIVIDER SOP INSTALLATION



#	Qty.	Description	Size	Part #
1	1	Glass Shower Divider	356	
2	N/A	Silicone Caulk	Clear	

1. From inside the shower compartment apply silicone caulk to inside of divider frame trim.
2. Press glass window into place.
3. Remove excess caulk from window and trim using alcohol.

Revision Dates:

Expected Time: 20 min.

Page