

356 SOP V-BERTH HANGING LOCKER PANELS INSTALLATION



#	Qty.	Description	Size	Part #
1	1	Port V-berth Aft Hanging Locker Panel	356	
2	1	Port V-berth Fwd Hanging Locker Panel	356	
3	1	Starboard V-berth Fwd Top Hanging Locker Panel	356	
4	1	Starboard V-berth Fwd Bottom Hanging Locker Panel	356	
5	1	Starboard V-berth Outboard Hanging Locker Panel	356	
6	1	Starboard V-berth Aft Hanging Locker Panel	356	
7	2	Starboard V-berth Shelves	356	
8	32	Panel Fasteners	#6 x 1/2" P/H	466790

1. The outboard edge of the port aft panel hanging locker may need to be scribed and cut about 1/4" so it will fit properly due to hull liner.
2. Secure the panel to the locker using the designated fasteners.
3. About 1/2" will probably need to be cut off the bottom of the port forward panel (measure to see if this is needed).
4. Place panel in locker to fit. Secure the panel to the locker using the designated fasteners.
5. On the strbd. outboard panel, top fwd corner, cut out a 1" x 1" square on panel for the light wire access.
6. Unscrew the strbd. fwd top panel and leave hanging. This is done so the strbd. outboard panel can be installed first.
7. Position panel in place. Secure the panel to the locker using the designated fasteners.
8. Place all other strbd. panels into place and secure with designated fasteners.
9. Snap locker doors onto hinges.

Revision Dates:

Expected Time: 60 min.

Page