

356 SOP VANITY & WET LOCKER TOWEL HOOKS INSTALLATION



#	#Ea.	Description	Size	Part #
1	3	Towel Hooks		
2	6	Hook Fasteners	6 x 1/2" P H	466790

1. There are three towel hooks located in the head area. Two are in the wet locker storage area, and one on the fwd vanity wall.
2. For the vanity wall hook, measure 6" down from the headliner and 8" outboard of the fwd inboard corner. Mark hole locations.
3. Using C-5 drill assembly, drill holes in marked locations.
4. Secure hooks using designated fasteners.
5. For the wet locker hooks, one is secured on the inboard wall 4" down and centered from the fwd and aft corners. The other hook is secured on the aft wall 4" down and 8" from the inboard aft corner trim. Mark hole locations.
6. Using C-5 drill assembly, drill holes in marked locations.
7. Secure hooks using designated fasteners.

Revision Dates:

Expected Time: 3 min.

Page