

## 356 SOP VANITY SINK TOP, and SHELF INSTALLATION



#	Qty.	Description	Size	Part #
1	1	Vanity Shelf	320	
2	4	Vanity Shelf Fasteners	#10 x 1-1/4" F/H	461410
3	1	Vanity Sink Top	320	

### Shelf Installation

1. On the outboard ends of the shelf battens mark 3-1/2" cut the battens off at this mark.
2. On the aft outboard corner of the shelf, where the hoses go through, trim off 1-1/2" following the curve.
3. Cut at a 30 degree angle off the outboard edge.
4. Place the vanity shelf inside the vanity and measure 13" up from the bottom of the vanity floor.
5. Level the vanity shelf and secure to the vanity using the designated fasteners through the designated battens.

### Vanity Top Installation

1. Replace the vanity cabinet top and re-secure.
2. Dry fit the vanity sink top. If the top fits continue with installation, if the top does not fit make the necessary adjustments for a flush fit.
3. Using designated caulk (See page 1 #1) caulk the top of the vanity cabinet.
4. Place the vanity sink top on the vanity cabinet and make sure the top is flush against the fwd and aft head bulkheads and the outboard panel.

Revision Dates:

Expected Time: 20 min.

Page