

356 SOP SEAHOOD INSTALLATION



1. Set the sea hood in place on top of the deck.
2. Drill holes using a C-7 drill assembly.
3. Remove the seahood then dremel the edges of the holes in deck to expose raw glass. Clean the deck and seahood with alcohol.
4. Caulk all mounting holes with designated caulk (page 1, #1).
5. Set the seahood back in place.
6. Secure the seahood to the deck using the designated fasteners.
7. Clean up excess caulk with alcohol.

#	#Ea.	Description	Size	Part #
1	1	Sea Hood	356	
2	9	Sea Hood Fasteners	#10 x 1 1/2" F/H	461330

Revision Dates:

Expected Time: 20 min.