- 1. Cutter stay chain plate will be mounted on anchorwell bulkhead thru deck, need to locate thru deck cutout for the chain plate, then drill 5 mounting holes on anchorwell bulkhead for #1/2" carriage thru bolts.
- Inside sail locker, Mount the cutter stay chainplate on anchorwell bulkhead (centerline), then mark thru deck cutout location, then cut a 2-1/8" x 5/8" rectangular cutout with ø1/8" relief at 4 corners of this thru deck cutout for cutter stay chainplate. (the size of rectangle cutout should satisify the size of chainplate), see the figure below
- 3. Insert cutter stay chain-plate from deck down into the rectangular cutout, the cover plate will sits on deck then mark chainplate mounting location on anchorwell bulkhead, then drill mounting holes for #1/2" carriage thru bolts. Drill 4 thru deck mounting holes for cover plate.
- 4. Apply marine sealant #795 white to caulk around all mounting holes including the rectangular thru deck hole.
- 5. Install cutter stay chainplate and backing plates using #1/2 carriage bolts and install cover plate of the chainplate using #1/4-20 machine screws.
- 6. Clean up excess caulk

