


41 DS AC DUCT WORK



	NAME	PART #	DIMENSIONS		
A	Cross over trunk line	H41DP259130 & H41DP259131	N/A		
B	Port forward trunk line	H41DP259132 & H41DP259133	N/A		
C	Connector flange	H41DP259153	2" X 8" X 3"		
D	Main transition box	H41DP259144 , (2)H41DP259151, H41DP259145 & H41DP259152	N/A		
E	Starboard forward trunk line	H41DP259134 & H41DP259135	N/A		
F	V-berth trunk line	H41DP259138 & H41DP259139	2" X 7-1/2" X 60"		
G	Compressor spacer plate	H41DP259150	N/A		
H	Aft stateroom trunk line	H41DP259142 & H41DP259143	2" X 7-1/2" X 46"		
I	Port aft trunk line	H41DP259136 & H41DP259137	2" X 7" X 56"		
J	Port galley trunk line	H41DP259140 & H41DP259141	2" X 7-1/2" X 48"		
K	Aft stateroom "Z" trunk line	H41DP259148 & H41DP259149	N/A		
L	Starboard aft trunk line	H41DP259136 & H41DP259137	2" X 7" X 42"		
M	Aft galley transition box	H41DP259146 & H41DP259147	N/A		

41 DS AC DUCT OUTLET LOCATION



Main Cabin Port Side Air Vents (8 vents)



Main Cabin Port Side Forward Section Air Vents



Main Cabin Starboard Side Air Vents (5 Vents)



Main Cabin Starboard Side Forward Sect Air Vents



Main Cabin Air Cond Control locates at fwd corner of the electrical panel by NAV station.




Fwd AC unit sits inside port fwd salon bunk



Fwd AC discharge thru hull ball valve

41 DS AC DUCT OUTLET LOCATION




Aft Cabin Starboard Side Air Vents (3 vents)




Aft Cabin Starboard Side Air Vents (3 vents)



Aft Cabin Air Cond Control Location



V berth Port side air vent layout location (3 vents)




Aft Cabin air return Grill location. Port Side Kick-board lower corner.

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

REVISIONS		DATE	APPROVED
ZONE	REV	DESCRIPTION	

41 AIR DUCT LAYOUT

- LEGEND —
- 1 - HALAGON W/D SWITCH
 - 2 - HALAGON W/SWITCH
 - 3 - DOME LIGHT
 - 4 - READING LIGHT
 - 5 - FLUORESCENT LIGHT
 - 6 - BAR FLUORESCENT



STAGE: ** TITLE: H41 AC DUCT WORK

ATTACH TO BOSS	SIZE FROM INL	DWG NO	SHEET 1 OF 1
WHISPER	A4	N/A	REV A