



41
Sofa Instruction




View of sofa the face plate




View of screws inside sofa behind the face plate


1. The top section of the sofa is secured to the bottom section at the front and rear and are accessed through the drawer openings.
2. Begin by removing the drawers, The drawer runners have tabs on the sides when pulled out to their limits, de-press the tabs to remove the drawer, See Photo # 7
3. Remove the screw inside the sofa behind the face plate, See Photos # 1 & 2.
4. Remove the screws at the rear of the sofa on the upper support, See Photos # 3 & 4.
5. Assembly of the sofa once inside the vessel is the reverse of the disassembly.
6. Secure the sofa in the main salon of the vessel to the sole by screwing through the base of the sofa into the sole, See Photos # 5 & 6.




View of screws at the rear of the sofa on the upper support



View of the base of the sofa at the back.



View of tab on drawer runner side




View of screws at the rear of the sofa on the upper support



View of assembled sofa with drawer installed



View of assembled sofa with drawer and seat cushions installed.



View of the base of the sofa at the front.