



NOTES:

- * MAST, MESSAGERS FOR MAIN, JIB, SPIN., AND STAYSAIL HALYARDS AND FOR BOOM AND SPIN. POLE TOPP. LIFTS. LEAD TO EXITS CORRESPONDING TO DECK PLAN
- * WINDEX MOUNTING LOCATION ON BACK OF CRANE.
- * SPARMAKER IS TO PROVIDE WIRING FOR STEAMING & DECK LIGHT AT TOP SPREADER, AND AN ANCHOR LIGHT AND VHF COAX CABLE AT TOP OF MAST.
- * VHF ANTENNA AND COAX CABLE IS SUPPLIED BY ELECTRONICS SUPPLIER AND INSTALLED BY THE MAST MFG.
- * ALL WIRES SHOULD EXIT AT BASE OF THE MAST
- * MAST STEP; PROVISIONS FOR LEADING AFT., 1 MAIN HAL., 1 GENOA HAL., 1 STAYSAIL HAL., 1 SPIN HAL., VANG, MAINSHEET, OUTHAUL AND INHAUL.
- * SPARMAKER IS TO INCLUDE SOLID BOOMVANG WITH SPRINGLOADED RETURN

HUNTERA
 H42 SAILPLAN, Z-SPAR FURLING MAST
 L'YNN
 .0416-1
 R00410
 H42-D-2114

NO.	SCALE	DATE	BY	CHKD.	APP.
1	AS SHOWN	SEPT 7, 90	L'YNN		
2					
3					
4					
5					
6					
7					
8					
9					
10					