

50cc FRESH WATER SYSTEM ARRANGEMENT

- 1 COCKPIT SHOWER (COLD & HOT)
- 2 AFT CABIN BATH TUB FAUCET (COLD & HOT)
- 3 MASTER SHOWER FAUCET (COLD & HOT)
- 4 MASTER VANITY FAUCET (COLD & HOT)
- 5 MASTER HEAD (COLD)

- 6 OPTIONAL WASHER AND DRYER (COLD & HOT)
- 7 CENTER WATER TANK (COLD)
- 8 WATER TANK MAINFOLD (COLD)
- 9 PORT GUEST SHOWER FAUCET (COLD & HOT)

- 10 FWD CABIN WATER HEATER
- 11 STARBOARD SIDE GUSSET HEAD (COLD)
- 12 STARBOARD VANITY FAUCET (COLD & HOT)
- 13 WATER HEATER
- 14 GALLEY FAUCET (COLD & HOT)

- 15 FRESH WATER PUMP (UNDER GALLEY SINK)
- 16 GALLEY MAINFOLD (UNDER GALLEY SINK)
- 17 STARBOARD FWD WATER TANK
- 18 STARBOARD AFT WATER TANK

CAUTION

Make sure that the water heater is full before energizing, bleed off any air by opening the hot water valve, close only when there is a steady flow of water, this will bleed the hot water system of air. Failure to follow these instructions could result in damage to the heating elements in your water heater.

WARNING

Allowing your boat to stay connected to dockside water supply while unattended, could result in a sunken boat. A major leak or break in the system could flood the bilges, excess water in the bilges could flood the batteries and result in your boat sinking.

Before connecting to a dockside water source, make certain the water is suitable for drinking. Water that may be of questionable quality could result in serious illness or death.

Hydrogen gas may form in a water heater if not used. You should always open the valves!

Do not smoke or use electrical appliances for several minutes before use.

water maker goes here