





Hunter 33

WIRING DIAGRAM (AC)




LEGEND:

- | | |
|--|--|
|  | ELECTRICAL DECK PLATE |
|  | SWITCH PANEL |
|  | WATER HEATER |
|  | 110v OUTLET |
|  | 10/3 MARINE POWER CABLE
(AC SUPPLY) |
|  | 14/2 MARINE POWER CABLE |


Hunter 33

WIRING DIAGRAM (DC)



LEGEND:

	BATTERY (2-72 A.)		SM. ROUND LIGHT
	SWITCH PANEL		L.G. ROUND LIGHT
	SAFETY MAIN SWITCH		L.G. FLUOR. LIGHT
	WATER PUMP		SM. FLUOR. LIGHT
	BILGE PUMP (750 GPH)		CHART LIGHT
	BILGE FLOAT SWITCH		IN-LINE FUSE
	MAST		KEEL
	BILGE PUMP/SHOWER (750 GPH)		FLUOR. LIGHT AT CHART TABLE IS RED.
	PUSH/PULL SWITCH		
	TERMINAL BLOCK		



DC SUPPLY TO SWITCH PANEL

WIRING NOTES:

COLOR	GAUGE	APPLICATION
RED	4	BATTERY CABLE/SAFETY MAIN SW.
RED	8	MAST GROUND
WHITE	10	DC SUPPLY TO SWITCH PANEL
RED	12	WATER PUMP
BLUE	16	CABIN LIGHTS
WHITE	16	RUNNING LIGHTS (BOW)
"	"	" (STERN/COMPASS)
GREEN	16	STEAMING LIGHTS
RED	16	ANCHOR LIGHT
BROWN	16	BILGE PUMP
TAN	16	BILGE FLOAT SWITCH

● ALL LEADS (EXCEPT FLOAT SWITCH AND MAST GROUND) ARE RUN WITH A BLACK GROUND OF EQUAL GAUGE. THESE ARE CONNECTED TO A COMMON GROUND AT THE SWITCH PANEL WHICH IS GROUNDED TO THE ENGINE WITH A 10 GAUGE BLACK WIRE.